PSR-MS30 / PSR-MS35

Safety relay for emergency stop and safety door monitoring



Data sheet
106168_en_03

© Phoenix Contact 2024-11-07

1 Description

Intended Use

The safety relays are used to monitor single or two-channel signal generators and to control actuators.

When the sensor circuit is interrupted, the safety relays initiate the safe state.

The safety relays interrupt circuits in a safety-related way.

Possible signal generators

- Emergency stop button
- Door locking mechanisms

Contact switching type

- 1 undelayed enabling current path

The enabling current path drops out without delay as per stop category 0 in accordance with EN 60204-1.

Control

- 1- or 2-channel
- Automatic start (PSR-MS30 only)
- Manual, monitored start (PSR-MS35 only)

Achievable safety integrity

- Suitable up to category 4, PL e (EN ISO 13849-1), SIL 3 (EN IEC 62061)

Additional features

- Cross circuiting detection
- Fixed screw connection
- 6.8 mm housing width

Approvals

c UL us LISTED

TÜVNORD Type Tested

Observe these notes

WARNING: Risk of electric shock

Observe the safety regulations and installation notes in the corresponding section.

Make sure you always use the latest documentation.
It can be downloaded from the product at phoenixcontact.com/products.

This document is valid for the products listed in the “Ordering data” chapter.

This document meets the same requirements as the original operating instructions with respect to the contents.

2 Table of contents

1 Description 1
2 Table of contents 2
3 Ordering data 3
4 Technical data 4
5 Interface type (ZVEI classification) 8
6 Notes regarding documentation 11
7 Safety regulations and installation notes 12
8 Transport, storage, and unpacking 13
9 Function description 14
10 Function and time diagrams 14
11 Block diagram 15
12 Derating 15
13 Relay data 16
14 Operating and indication elements 17
15 Mounting and removing 18
16 Wiring 18
17 Startup 19
18 Calculating the power dissipation 20
19 Function test/proof test 20
20 Diagnostics 21
21 Application examples 23
22 Device replacement, device defect, and repair 27
23 Maintenance, decommissioning, and disposal 27
24 Attachment 28

3 Ordering data

Description	Type	Item no.	Pcs./Pkt.
Safety relay for emergency stop and safety doors up to SILCLSIL 3, Cat. 4, PL e, 1 or 2-channel operation, automatic start, cross-circuit detection, 1 enabling current path, U_S = 24 V DC, fixed screw terminal block	PSR-MS30-1NO-24DC-SC	2904952	1
Safety relay for emergency stop and safety doors up to SIL 3, Cat. 4, PL e, 1 or 2-channel operation, manual, monitored start, cross-circuit detection, 1 enabling current path, U_S = 24 V DC, fixed screw terminal block	PSR-MS35-1NO-24DC-SC	2904953	1

Accessories	Type	Item no.	Pcs./Pkt.
Zack Marker strip, flat, Strip, white, unlabeled, can be labeled with: PLOTMARK, CMS-P1-PLOTTER, mounting type: latching, for terminal block width: 6.2 mm, Number of individual labels: 10, text field height: 6.15 mm, text field width: 5.15 mm	ZBF 6:UNBEDRUCKT	0808710	10
Crimping pliers, for ferrules without insulating collar according to DIN 46228 Part 1 and ferrules with insulating collar according to DIN 46228 Part 4, 0.25 mm² ... 6.0 mm², lateral entry, trapezoidal crimp	CRIMPFOX 6	1212034	1
Module holder for modular emergency stop switches, connects the contact block and actuator with bayonet lock, suitable for 3 elements	PSR-ESS-ACC-CB1-C3	1221747	1
Contact module for modular emergency stop switches with force-guided N/C contact for safety-related shutdown, in conjunction with appropriate evaluation unit suitable for use up to PL e (EN ISO 13849-1), SIL 3 (EN IEC 62061)	PSR-ESS-ACC-CB1-NC-SC	1221752	1
Actuator with anti-lock collar for modular emergency stop switches, for combination with module holder and contact module as a functional unit, panel installation, bayonet lock	PSR-ESS-M0-H110	1221757	1

4 Technical data

Hardware/firmware version	
HW/FW	≥ 02/--
The technical data and safety characteristics are valid as of the specified HW/FW version.	
Supply: A1/A2	
Rated control circuit supply voltage U_S	24 V DC -15 % / +10 %
Rated control circuit supply voltage U_S	20.4 V DC ... 26.4 V DC
Rated control supply current I_S	typ. 42 mA
Power consumption at U_S	typ. 1 W
Inrush current	4.5 A (Δt < 120 µs at U_s)
Filter time	1 ms (at A1 in the event of voltage dips at U_s)
Protective circuit	Surge protection, Suppressor diode
	Serial protection against polarity reversal
Digital inputs: Sensor circuit (S12, S22)	
Number of inputs	2
Description of the input	safety-related sensor inputs
Input voltage range "0" signal	0 V DC ... 5 V DC (for safe Off; at S12)
Input current range "0" signal	0 mA ... 2 mA (for safe Off; at S12)
Input voltage range "1" signal	20.4 V DC ... 26.4 V DC
Inrush current	< 20 mA (typ. with U_S at S12) < 5 mA (typ. with U_S at S22) > -15 mA (typ. with U_S at S22/0 V)
Current consumption	< 5 mA (with U_s/I_x to S12) < 5 mA (with U_s/I_x to S22) > -5 mA (with U_s/I_x to S22/0V)
Filter time	max. 1.5 ms (Test pulse width of low test pulses) Test pulse rate = 5 x Test pulse width
Max. permissible overall conductor resistance	150 Ω
Protective circuit	Suppressor diode
Digital inputs: Start circuit (S35)	
Number of inputs	1
Description of the input	non-safety-related
Input voltage range "1" signal	20.4 V DC ... 26.4 V DC
Inrush current	< 10 mA
Current consumption	< 10 mA
Max. permissible overall conductor resistance	150 Ω
Protective circuit	Suppressor diode

Relay outputs: Enabling current path (13/14)	
Number of outputs	1 (undelayed)
Output description	safety-related N/O contacts
Contact material	$AgSnO_2$
Switching voltage (see section “Relay data”)	min. 12 V AC/DC max. 250 V AC/DC
Limiting continuous current (see section “Relay data”)	6 A
Inrush current	min. 3 mA max. 6 A
Sq. Total current $I_{TH}^2 = I_1^2 + I_2^2 + ... + I_N^2$	36 A^2 (observe derating)
Switching capacity	min. 60 mW
Switching frequency	max. 0.1 Hz
Service life electrical	See section “Electrical service life”
Mechanical service life	10x 10^6 cycles
Switching capacity in accordance with IEC 60947-5-1	5 A (AC15) 4 A (DC13)
Output fuse	6 A gL/gG 4 A gL/gG (for low-demand applications)

Times	
Typical starting time with U_s	< 250 ms (when controlled via A1)
Typical response time at U_s	< 175 ms
Typical release time with U_s	< 20 ms (when controlled via A1 or S12 and S22.)
Restart time	1 s (Boot time, after switching on the supply voltage)
Recovery time	< 500 ms

General data	
Relay type	Electromechanical relay with force-guided contacts in accordance with IEC/EN 61810-3
Nominal operating mode	100% operating factor
Degree of protection	IP20
Min. degree of protection of inst. location	IP54
Mounting type	DIN rail mounting
Mounting position	vertical or horizontal
Assembly note	See derating curve
Dimensions (W/H/D)	6.8 x 93.1 x 102.5 mm
Type of housing	PBT zinc yellow (RAL 1018)
Operating voltage display	1 x green LED
Status display	2 x LED (green)
Air clearances and creepage distances between the power circuits	according to EN 60947-1
Rated insulation voltage	250 V AC
Rated surge voltage/insulation	See “Insulation coordination”
Degree of pollution	2
Overvoltage category	III
Maximum power dissipation for nominal condition	3 W (U_S = 26.4 V, I_L^2 = 36 A², $P_{Total\ max}$ = 1.2 W + 1.8 W)
Note on power dissipation	See “Calculating the power dissipation”

Connection data	
Connection method	Screw connection
Conductor cross section rigid	0.2 mm² … 2.5 mm²
Conductor cross section flexible	0.2 mm² … 2.5 mm²
Conductor cross-section AWG	26 … 12
Stripping length	12 mm
Screw thread	M3
Tightening torque	0.5 Nm … 0.6 Nm

Ambient conditions	
Ambient temperature (operation)	-40 °C … 60 °C (observe derating)
Ambient temperature (storage/transport)	-40 °C … 85 °C
Max. permissible relative humidity (operation)	75 % (on average, 85% infrequently, non-condensing)
Max. permissible humidity (storage/transport)	75 % (on average, 85% infrequently, non-condensing)
Maximum altitude	≤ 2000 m (Above sea level)
Information on operating height	See the “Using PSR devices at altitudes greater than 2000 m above sea level” section
Shock	15g
Vibration (operation)	10 Hz … 150 Hz, amplitude 0.15 mm, 2g

Conformance/Approvals
Content of the EU Declaration of Conformity: The product conforms with the most important requirements of the following directive(s) and their modification directives: - 2006/42/EC Machinery Directive - 2014/30/EU Electromagnetic Compatibility Directive (EMC) The full EU Declaration of Conformity can be downloaded from the product page at www.phoenixcontact.com/products.
The latest approvals can be downloaded from the product page at www.phoenixcontact.com/products.

Safety data	
Stop category according to IEC 60204	0

Safety parameters in accordance with IEC 61508 - high demand	
IEC 61508 - High demand	
Equipment type	Type A
HFT	1
SIL	3
PFH_D	1.5×10^{-9} (4 A DC13; 5 A AC15; 8760 switching cycles/year)
Demand rate	< 12 Months
Proof test interval	240 Months
Mission time	240 Months

Safety technology parameters according to IEC 61508 - low demand	
Equipment type	Type A
HFT	1
SIL	3
PFD_{avg}	1.47×10^{-4}
Proof test interval	60 Months
Mission time	240 Months

Safety parameters according to EN ISO 13849-1	
Category	4
Performance level	e (4 A DC13; 5 A AC15; 8760 switching cycles/year)
Mission time	240 Months
For applications in PL e, the required demand rate for the safety function is once per month.	

Safety parameters in accordance with EN IEC 62061	
SIL	3
For applications in SIL 3 the required demand rate for the safety function is once per month.	

5 Interface type (ZVEI classification)

Digital inputs : Sensor circuit S12, S22				
Source/destination	**Interface type**	**Additional measure**	**Source/destination**	**Suitable interface type**
Destination	A	M	Source	A
Destination	C0	M	Source	C1, C2, C3

Interface type A - Destination			
Parameter	**min.**	**typ.**	**max.**
Input current I_i (in the ON-state)	> 2 mA	-	< 20 mA
Output voltage U_i	18.4 V	-	25 V
Input capacitance C_i	-	-	-
Additional measure M	- The inputs are not types in accordance with IEC 61131-2. - T_G is S11 for S12/S22 (24 V without cycle). - T_G is A2 for S22 (0 V without cycle).		

Interface type C0 - Destination			
Parameter	**min.**	**typ.**	**max.**
Test pulse duration t_i	-	-	1.5 ms
Test pulse interval T	7.5 ms	-	-
Input resistance R	6 kΩ	-	-
Input capacitance C_L	-	-	-
Inductive load L_L	-	-	-
Additional measure M	- The inputs are not types in accordance with IEC 61131-2. - Switch-on pulses should be switched off for safety applications. - Not suitable with sources containing discharge circuits.		

Digital inputs : Start circuit S35				
Source/destination	**Interface type**	**Additional measure**	**Source/destination**	**Suitable interface type**
Destination	A	M	Source	A
Destination	C0	M	Source	-

Interface type A - Destination			
Parameter	**min.**	**typ.**	**max.**
Input current I_i (in the ON-state)	> 1.8 mA	-	10 mA
Output voltage U_i	18.4 V	-	25 V
Input capacitance C_i	-	-	-
Additional measure M	- The inputs are not types in accordance with IEC 61131-2. - T_G is S11 for S35 (autostart)		

Interface type C0 - Destination			
Parameter	**min.**	**typ.**	**max.**
Test pulse duration t_i	-	-	-
Test pulse interval T	-	-	-
Input resistance R	10 kΩ	-	-
Input capacitance C_L	-	-	-
Inductive load L_L	-	-	-
Additional measure M	- The inputs are not types in accordance with IEC 61131-2. - No test pulses are allowed when controlling with a source.		

Relay outputs : Enabling current path 13/14				
Source/destination	**Interface type**	**Additional measure**	**Source/destination**	**Suitable interface type**
Source	A	M	Destination	A
Source	C0	M	Destination	-

Interface type A - Source			
Parameter	**min.**	**typ.**	**max.**
Switching current I_i	3 mA	-	6 A
Switching voltage U_i	12 V	-	250 V AC/DC
Internal resistance R_i (in the switched state)	Load 6 A < 50 mΩ	-	Load 10 mA < 20 Ω
Load capacitance C_L	-	-	see switching capacity
Inductive load L_L	-	-	see switching capacity
Electrical isolation	yes		
Additional measure M	- The outputs are not types in accordance with IEC 61131-2.		

Interface type C0 - Source			
Parameter	**min.**	**typ.**	**max.**
Test pulse duration t_i	-	-	-
Test pulse interval T	-	-	-
Nominal current I_N	-	-	6 A
Load capacitance C_L	-	-	see switching capacity
Inductive load L_L	-	-	see switching capacity
Additional measure M	- The outputs are not types in accordance with IEC 61131-2. - No test pulses are emitted at the output.		

6 Notes regarding documentation

6.1 Identification of warning notes



This symbol indicates hazards that could lead to personal injury.

There are three signal words indicating the severity of a potential injury.

DANGER Indicates a hazard with a high risk level. If this hazardous situation is not avoided, it will result in death or serious injury.

WARNING Indicates a hazard with a medium risk level. If this hazardous situation is not avoided, it could result in death or serious injury.

CAUTION Indicates a hazard with a low risk level. If this hazardous situation is not avoided, it could result in minor or moderate injury.



This symbol together with the **NOTE** signal word warns the reader of actions that might cause property damage or a malfunction.



Here you will find additional information or detailed sources of information.

6.2 Validity

This data sheet is valid for the described product(s) from the hardware/firmware version specified in the technical data.

6.3 Target group

This data sheet is therefore aimed at:

– Qualified personnel who plan and design safety equipment for machines and systems and are familiar with regulations governing occupational safety and accident prevention.
– Qualified personnel who install and operate safety equipment in machines and systems.

Qualified personnel:

Qualified personnel are people who, because of their education, experience, and instruction and their knowledge of relevant standards, regulations, accident prevention, and service conditions, have been authorized by those responsible for the safety of the system to carry out any required operations and who are able to recognize and avoid any possible dangers.

Requirements:

Knowledge of the following topics is required:

– Handling safety components
– Valid EMC regulations
– Valid regulations governing occupational safety and accident prevention

7 Safety regulations and installation notes

WARNING: Death, serious personal injury or damage to equipment

Depending on the application, incorrect handling of the device may pose serious risks for the user or cause damage to equipment.

- Observe all the safety notes and warning instructions provided in this chapter and elsewhere in this document.

General

The device contains components that can be damaged or destroyed by electrostatic discharge.

- When handling the device, observe the necessary safety precautions against electrostatic discharge (ESD) in accordance with EN 61340-5-1 and IEC 61340-5-1.

Direct/indirect contact

- Protection against direct and indirect contact according to VDE 0100 Part 410 must be ensured for all components connected to the system.

In the event of an error, parasitic voltages must not occur (single-fault tolerance).

Power supply units for 24 V supply

- Only use power supply units with safe isolation and SELV/PELV.
- Protect the 24 V area with a suitable external fuse.
- Make sure that the power supply unit is able to supply **four times** the nominal current of the external fuse, to ensure that it trips in the event of an error.

Startup, mounting, and modifications

Startup, mounting, modifications, and upgrades may only be carried out by qualified personnel.

- Before working on the device, disconnect the power.
- Carry out wiring according to the application. Refer to the “Application examples” section for this.

Reliable operation is only ensured if the device is installed in housing protected from dust and humidity.

- Install the device in housing protected from dust and humidity (min. IP54).

In operation

During operation, parts of electrical switching devices carry hazardous voltages.

- Protective covers must not be removed when operating electrical switching devices.

For emergency stop applications, automatic startup of the machine can pose serious risks for the user.

- The machine must be prevented from restarting automatically by a higher-level controller.

With the manual, monitored reset device, a machine start may not be triggered in accordance with EN ISO 13849-1.

Inductive loads can lead to welded relay contacts.

- Connect a suitable and effective protective circuit to inductive loads.
- Implement the protective circuit parallel to the load and not parallel to the switch contact.

Magnetic fields can influence the device. The magnetic field strength of the environment must not exceed 30 A/m.

- Do not use the device in the vicinity of strong magnetic fields (e.g., caused by transformers or magnetic iron).

EMC notes

Noise emission may occur when operating relay modules. Wireless reception may be disrupted in residential areas.

The device is a Class A product.

- Observe the requirements for noise emission for electrical and electronic equipment (EN 61000-6-4).
- Implement appropriate precautions against noise emission.

Faulty devices

The devices may be damaged following an error. Correct operation can no longer be ensured.

- Replace any defective devices.

Only the manufacturer or their authorized representative may perform the following activities. Otherwise the warranty is invalidated.

– Repairs to the device
– Opening the housing

Replacing the device

- Dispose of the device in the following circumstances:

– At the end of its mission time

🛈 See “Technical data” section.

– At the end of its electrical service life

🛈 See section “Electrical service life”.

– In the event of a fault

7.1 Safety of machines or systems

Draw up and implement a safety concept

The machine or system manufacturer and the operator are responsible for the safety of the machine or system and the application in which the machine or system is used. In order to use the device described in this document, you must have drawn up an appropriate safety concept for your machine or system. This includes a risk assessment in accordance with the directives and standards specified in the EC Declaration of Conformity, as well as other standards.

Risk assessment, validation and function test

- Before using the device, perform a risk assessment on the machine or system.
- Validate your entire safety system.
- Carry out a new validation every time you make a safety-related modification.
- Perform a function test on a regular basis.

Achievable safety integrity

The functional safety is ensured for the device as a single component. However, this does not guarantee functional safety for the entire machine or system. In order to be able to achieve the desired safety level for the entire machine or system, define the safety requirements for the machine or system as well as how to implement them from both a technological and an organizational perspective.

8 Transport, storage, and unpacking

8.1 Transport

The device is delivered in cardboard packaging.

- Observe the instructions on how to handle the package indicated on the packaging.

Suitable transport packaging

- Only transport the device in its original packaging or in packaging suitable for transport.

Technical data and environmental conditions

- For transport, observe the humidity and air pressure specifications, and the temperature range.
  🛈 See Section “Technical data”.

8.2 Storage

Suitable storage location

The storage location must meet the following requirements:

– Dry
– Protected against unauthorized access
– Protected against harmful environmental influences such as UV light

Technical data and environmental conditions

- For storage, observe the humidity and air pressure specifications, and the temperature range.
  🛈 See Section “Technical data”.

8.3 Unpacking

The device is delivered in packaging together with a packing slip that provides installation instructions.

Observing the packing slip

- Read the entire packing slip carefully.
- Retain the packing slip.

Checking the delivery

- Check the delivery for damage and completeness.
- Submit any claims for transport damage immediately.

Scope of supply

Refer to the ordering data for the standard scope of supply for the product.
🛈 See Section “Ordering data”.

9 Function description

9.1 Single-channel sensor circuit

The sensor circuit is not designed with redundancy.

The safety relay does not detect short and cross-circuits in the sensor circuit.

9.2 Two-channel sensor circuit

The sensor circuit is designed with redundancy.

With the corresponding wiring, the safety relay detects short and cross-circuits in the sensor circuit.

9.3 Automatic start

PSR-MS30 only

The device starts automatically after the sensor circuit has been closed.

9.4 Manual, monitored start

PSR-MS35 only

When the sensor circuit is closed, the device starts once the start circuit has been closed and opened again by pressing and releasing the reset button.

A connected reset button is monitored.

9.5 Safe shutdown


When the sensor circuit opens, the enabling current path opens without delay.

When the enabling current path is open, the device is in the safe state.

10 Function and time diagrams


10.1 Time diagram PSR-MS30

Figure 1 Time diagram PSR-MS30



10.2 Time diagram PSR-MS35

Figure 2 Time diagram PSR-MS35




Key:

1	Automatic start
2	Start via external signal at S35 which is not monitored
A1/A2	Power supply
S35 (PSR-MS30 only)	Automatic start
S34 (PSR-MS35 only)	Manual, monitored start
S12	Input sensor circuit (channel 1)
S22	Input sensor circuit (channel 2)
13/14	Enabling current path, undelayed

11 Block diagram


11.1 Block diagram PSR-MS30

Figure 3 Block diagram PSR-MS30



11.2 Block diagram PSR-MS35

Figure 4 Block diagram PSR-MS35



Key:

A1	24 V DC power supply
A2	0 V power supply
S11	Output 24 V
S12	Input sensor circuit (channel 1)
S22	Input sensor circuit (channel 2)
S35 (PSR-MS30 only)	Automatic start
S34 (PSR-MS35 only)	Manual, monitored start
13/14	Enabling current path, undelayed

Insulation coordination:

	A1/A2, logic	13/14	Housing
A1/A2, logic	-	6 kV ST	4 kV BI
13/14	-	-	4 kV BI

Key:

BI	Basic insulation
ST	Safe isolation
Logic	Sensor and start circuits, signal output

Safe isolation/reinforced insulation

(rated surge voltage of 6 kV)

Reinforced insulation (e.g., thanks to greater air clearances and creepage distances between conductive paths) is designed for one overvoltage category higher than basic insulation. This means that SELV circuits of U ≤ 25 V AC or U ≤ 60 V DC and circuits with higher voltages can be mixed.


12 Derating

12.1 Vertical or horizontal mounting position

The derating curve applies for the following conditions:

– Mounting on a vertical or horizontal DIN rail
– Devices mounted next to each other without spacing

Figure 5 Derating curve - vertical or horizontal mounting position, without spacing




13 Relay data

13.1 Load limit curve at DC load

Ohmic and inductive load

Figure 6 Load limit curve - ohmic and inductive load




Key:

1	Ohmic load	L/R = 0 ms
2	Inductive load	L/R = 40 ms

13.2 Electrical service life

Figure 7 Electrical service life for high-demand applications



Behavior of the electrical service life

The service life curves indicate the number of switching cycles after which wear-related failures must be expected.

They depend on the utilization category and the expected load current.

Example:

Let's assume:

– Inductive load = 1 A
– Utilization category = AC15

This results in a contact service life of 300000 switching cycles.

WARNING: Loss of functional safety


At the end of the electrical service life, there is an increased risk of loss of functional safety.

- Replace the device in good time before the end of the electrical service life.

14 Operating and indication elements

14.1 Connection versions

Figure 8 Connection versions




1 Fixed screw connection

2 Snap-on foot for DIN rail mounting

The year the device was constructed can be found underneath the CE designation on the housing.

14.2 Connection assignment




A1	24 V DC power supply
A2	0 V power supply
S11	Output 24 V
S12	Input sensor circuit (channel 1)
PWR	Power, LED (green)
IN	Status indicator sensor circuit; LED (green)
K1/K2	Status indicator safety circuit, LED (green)
S35 (PSR-MS30 only)	Automatic start
S34 (PSR-MS35 only)	Manual, monitored start
13/14	Enabling current path, undelayed
S22	Input sensor circuit (channel 2)

15 Mounting and removing

- Mount the device on a 35 mm DIN rail in accordance with EN 60715.
- To remove the device, use a screwdriver to release the snap-on foot.


Figure 9 Mounting and removing



16 Wiring

- Connect the cables to the connection terminal blocks using a screwdriver.

Figure 10 Connection of the cables



It is recommended that ferrules are used to connect stranded cables.

Use the CRIMPFOX 6 crimping tool from Phoenix Contact.


The tool enables the reliable processing of ferrules and easy removal of conductors with ferrules from the connection terminal blocks.

For compliance with UL approval, use copper wire that is approved up to 60°C/75°C.

16.1 Signal generator connection versions

- Connect suitable signal generators to S11/S12/S22.

Figure 11 Signal generator connection versions



1 2-channel connection with cross-circuit monitoring
2 2-channel connection without cross-circuit monitoring
3 1-channel connection

16.2 Start and feedback circuit connection variants

Automatic start (PSR-MS30 only)

- Bridge the contacts S11/S35.

Manual, monitored start (PSR-MS35 only)


- Connect a reset button to contacts S11/S34 an.

A connected reset button is monitored.

Start and feedback circuit

- Place the relevant N/C contacts in path S11/S34 or S11/S35 to monitor external contactors or extension devices with force-guided contacts.

Figure 12 Start and feedback circuit connection variants



1 Automatic start
2 Automatic start with monitored contact extension
3 Manual, monitored start with monitored contact extension
4 Manual, monitored start

17 Startup

- Apply the rated control circuit supply voltage (24 V DC) at terminal blocks A1/A2.

The Power LED lights up.

- Close the sensor circuit at S11/S12/S22 as per the wiring.

The IN LED lights up.

1- or 2-channel sensor circuit: see section “Signal generator connection versions”.

Automatic start (PSR-MS30 only)

Enabling current path 13/14 closes.

The K1/K2 LED lights up.

Manual, monitored start (PSR-MS35 only)

- Press the reset button.
- Release the reset button.

Enabling current path 13/14 closes.

The K1/K2 LED lights up.

18 Calculating the power dissipation

The total power dissipation of the safety relay is based on the input power dissipation and the contact power dissipation for the same and for different load currents.

Input power dissipation

$P_{Input} = U_B^2 / (U_S/I_S)$

Contact power dissipation

$P_{Contact} = (I_{L1}^2 + I_{L2}^2 + ... + I_{Ln}^2) \bullet 50\ m\Omega$

Total power dissipation

$P_{Total} = P_{Input} + P_{Contact}$

$P_{Total} = U_B^2 / (U_S/I_S) + (I_{L1}^2 + I_{L2}^2 + ... + I_{Ln}^2) \bullet 50\ m\Omega$

Key:

P	Power dissipation in mW
U_B	Applied operating voltage
U_S	Rated control circuit supply voltage
I_S	Rated control supply current
I_L	Contact load current

19 Function test/proof test

To verify the device function, proceed as follows:

- Demand the safety function by actuating the corresponding safety equipment.
- Check whether the safety function was executed correctly by switching the device on again.

If the device does not switch on again, the proof test failed.

WARNING: Loss of functional safety due to malfunction

If the proof test contains errors, the device no longer functions correctly.

- Replace the device.

20 Diagnostics

Plausibility errors are deleted when the supply voltage is switched off (power down reset).

20.1 General states

Key:

○ LED OFF
● LED ON

LED			State	Notes
PWR	IN	K1/K2		
●	○	○	No relays are activated. The sensor circuit is inactive.	Possible error see error messages
●	●	○	The sensor circuit is active. Relays K1 and K2 are ready to start and await reset/start command (S34 or S35).	
●	●	●	The sensor circuit is active. All relays are picked up.	-

20.2 Error messages

Key:

○ LED OFF
● LED ON

LED			State	Possible cause	Corrective
PWR	**IN**	**K1/K2**			
●	○	○	The sensor circuit is actively controlled, but no input LEDs are lit up.	Internal cross-circuit detection is active: potential cross-circuit in the sensor circuit.	Switch off the operating voltage and rectify the cross-circuit. Then perform a function test.
●	●	○	The sensor circuit is active. The reset/start circuit (S34 or S35) is/was activated. The safety circuit (K1 and K2) is not picking up.	External error: the readback contact (external actuator) is open in the reset circuit. Internal error: 1. The diagnostic contact is not working correctly. 2. An N/O contact is welded.	External error: check the actuator. Internal error: perform a power down reset with subsequent function test. **If the error occurs again after the function test, replace the device.**
●	●	○	The sensor circuit is active. The reset/start circuit (S34 or S35) is/was activated. The safety circuit (K1 and K2) is not picking up.	Error in the sensor circuit.	Check the sensor circuit. Then perform a function test. **If the error occurs again after the function test, replace the device.**
●	●	○	The sensor circuit is active. The reset/start circuit (S34) is/was activated. The safety circuit (K1 and K2) is not picking up.	Error during manual reset S34 (stuck-at at the input).	Remove the error in the reset/start circuit. Then perform a function test.
○	○	○	The sensor circuit is active.	1. No supply voltage at A1/A 2. Over- or undervoltage at A1	Check the supply voltage.

21 Application examples

Applications with the PSR-MS30

21.1 Emergency stop monitoring/automatic start

Application description:


- 2-channel emergency stop monitoring
- Automatic start
- Monitoring of external, force-guided contactors

Achievable safety integrity:

- Suitable up to category 4, PL e (EN ISO 13849-1), SIL 3 (EN IEC 62061), if cross-circuits in the control to the actuator can be ruled out

Cross-circuits in the cable installation can be excluded if the safety relay and external contactors K1 and K2 are located in the same electrical installation space.

Figure 13 Emergency stop monitoring/automatic start



Key:

S1	Emergency stop button
K1/K2	Force-guided contactors

21.2 Safety door monitoring/automatic start

Application description:


- 2-channel safety door monitoring
- Automatic start
- Monitoring of external, force-guided contactors

Achievable safety integrity:

- Suitable up to category 4, PL e (EN ISO 13849-1), SIL 3 (EN IEC 62061), if cross-circuits in the control to the actuator can be ruled out

Cross-circuits in the cable installation can be excluded if the safety relay and external contactors K1 and K2 are located in the same electrical installation space.

Figure 14 Safety door monitoring/automatic start



Key:

B1/B2	Mechanical safety door switches
K1/K2	Force-guided contactors

21.3 Magnetic switch monitoring/automatic start

Application description:


- 2-channel magnetic switch monitoring
- Automatic start
- Monitoring of external, force-guided contactors

Achievable safety integrity:

- Suitable up to category 4, PL e (EN ISO 13849-1), SIL 3 (EN IEC 62061), if cross-circuits in the control to the actuator can be ruled out

Cross-circuits in the cable installation can be excluded if the safety relay and external contactors K1 and K2 are located in the same electrical installation space.

Figure 15 Magnetic switch monitoring/automatic start



Key:

S3	Solenoid switch
K1/K2	Force-guided contactors

Applications with the PSR-MS35

21.4 Emergency stop monitoring/manual, monitored start

Application description:


- 2-channel emergency stop monitoring
- Manual, monitored start
- Monitoring of external, force-guided contactors

Achievable safety integrity:

- Suitable up to category 4, PL e (EN ISO 13849-1), SIL 3 (EN IEC 62061), if cross-circuits in the control to the actuator can be ruled out

Cross-circuits in the cable installation can be excluded if the safety relay and external contactors K1 and K2 are located in the same electrical installation space.

Figure 16 Emergency stop monitoring/manual, monitored start



Key:

S1	Emergency stop button
S2	Manual reset device
K1/K2	Force-guided contactors

21.5 Safety door monitoring/manual, monitored start

Application description:


- 2-channel safety door monitoring
- Manual, monitored start
- Monitoring of external, force-guided contactors

Achievable safety integrity:

- Suitable up to category 4, PL e (EN ISO 13849-1), SIL 3 (EN IEC 62061), if cross-circuits in the control to the actuator can be ruled out

Cross-circuits in the cable installation can be excluded if the safety relay and external contactors K1 and K2 are located in the same electrical installation space.

Figure 17 Safety door monitoring/manual, monitored start



Key:

S2	Manual reset device
B1/B2	Mechanical safety door switches
K1/K2	Force-guided contactors

21.6 Magnetic switch monitoring/manual, monitored start

Application description:


- 2-channel magnetic switch monitoring
- Manual, monitored start
- Monitoring of external, force-guided contactors

Achievable safety integrity:

- Suitable up to category 4, PL e (EN ISO 13849-1), SIL 3 (EN IEC 62061), if cross-circuits in the control to the actuator can be ruled out

Cross-circuits in the cable installation can be excluded if the safety relay and external contactors K1 and K2 are located in the same electrical installation space.

Figure 18 Magnetic switch monitoring/manual, monitored start



Key:

S2	Manual reset device
S3	Solenoid switch
K1/K2	Force-guided contactors

22 Device replacement, device defect, and repair

22.1 Device replacement

The device can be replaced, if necessary.

If you need to replace the device, proceed as described in the following section:

– Mounting and removal
– Wiring

Observe the device type and version

The new device must meet the following requirements:

– Same device type
– Same or later version

22.2 Device defect and repair

Do not open the housing

Repairs may only be carried out by Phoenix Contact. Do not open the housing. If the housing is opened, the function of the device can no longer be ensured.

Faulty devices

- Please contact Phoenix Contact.

23 Maintenance, decommissioning, and disposal

23.1 Maintenance

The device requires no maintenance during the permissible mission time. Refer to the technical data for the mission time of the device.

If necessary, carry out proof tests within the specified proof test interval.

See “Technical data” section.

Depending on the application and connected I/O devices, you should test the function of the I/O devices and the safety chain regularly.

Observe the relevant manufacturer specifications for carrying out maintenance on connected I/O devices.

23.2 Decommissioning and disposal

Carry out decommissioning according to the requirements of the machine or system manufacturer.

When decommissioning the system or parts of the system, ensure the following for the devices used.

The device continues to be used only as intended:

- Observe the storage and transport requirements.

See “Transport, storage, and unpacking” section.

The device is not used any more:

The symbol with the crossed-out trash can indicates that this item must be collected and disposed of separately from other waste.
Phoenix Contact or public collection sites will take the item back for free disposal. For information on the available disposal options, visit www.phoenixcontact.com.

Packaging disposal

- Dispose of packaging materials that are no longer needed (cardboard packaging, paper, bubble wrap sheets, pillow bags, etc.) with household waste in accordance with the currently applicable national regulations.

24 Attachment

24.1 Using PSR devices at altitudes greater than 2000 m above sea level

The following section describes the special conditions for using PSR devices at altitudes greater than 2000 m above sea level.
Observe the relevant device-specific data (technical data, derating, etc.) according to the product documentation for the individual device.

Using the device at altitudes **greater than 2000 m above sea level up to max. 4500 m above sea level** is possible under the following conditions:

1. Limit the rated control circuit supply voltage (U_S) in accordance with the table below. Observe the technical data for the device.

U_S according to the technical data for the device	U_S when used at altitudes greater than 2000 m above sea level
< 150 V AC/DC	U_S according to the technical data for the device still valid
> 150 V AC/DC	Limited to max. 150 V AC/DC

2. Limit the maximum switching voltage in accordance with the table below. Observe the technical data for the device.

Max. switching voltage according to the technical data for the device	Max. switching voltage when used at altitudes greater than 2000 m above sea level
< 150 V AC/DC	Max. switching voltage according to the technical data for the device still valid
> 150 V AC/DC	Limited to max. 150 V AC/DC

3. Reduce the maximum ambient temperature for operation by the corresponding factor in accordance with the table below.
4. If derating is specified, offset all the points of the derating curve by the corresponding factor in accordance with the table below.

Altitude above sea level	Temperature derating factor
2000 m	1
2500 m	0.953
3000 m	0.906
3500 m	0.859
4000 m	0.813
4500 m	0.766


Example calculation for 3000 m

The following calculation and the illustrated derating curve are provided as examples.
Perform the actual calculation and offset the derating curve for the device used according to the technical data and the “Derating” section.

27 °C • 0.906 ≈ 24 °C

55 °C • 0.906 ≈ 49 °C

Figure 19 Example of a suspended derating curve (red)



24.2 Revision history

Version	Date	Contents
00	2014-12-03	First publication
01	2015-03-05	Reverse polarity protection extended; relay type extended; dimensions updated; load curve extended
02	2016-10-14	New edition of the data sheet: layout and structure revised; input voltage range and input current for “0” signal extended; output data (min. switching voltage) adjusted; relay type modified; note added regarding the protection of the 24 V area; inductive load curve extended; connection reset in Figure 11 adjusted; section on use at altitudes greater than 2000 m above sea level extended
03	2024-10-23	Ordering data section: new accessories; Technical data section: new structure, enabling current paths, switching frequency changed; new sections: Interface type (ZVEI classification); Notes on documentation; Transport, storage, and unpacking; Relay data; Function test/proof test; Device replacement, device defects, and repairs; Maintenance, decommissioning, and disposal; revised sections: Safety regulations and installation notes; Block diagram; Wiring.