

Push button stations including selector switches and pilot lights, Mono-lever operator-ARN may be followed by S or L, followed by 1, 2, 3 or 4, may be followed by numbers and/or letters, for use with Contact block; Model BR; S Series (Panel Cutout Dimensions, 25mm diam).

- (1) Push button Switches, Types ATS, UTS, ABBS.
 - (2) Illuminated Push button Switches, Types ALLS, ABLs.
 - (3) Pilot lights, Types APS, UPQS, TWTD/TWT Series (Panel Cutout Dimensions, 30mm diam Series).
 - (1) Push button Switches Types AB, AO, AJ, AT, AV, AY or AZ may be followed by F or G, followed by D, Types AJN, AVN. ALTERNATE: Type AB*D or AO*D.
 - (2) Selector Switches Type ASD.
 - (3) Selector Push button Switches Type ASBD.
 - (4) Illuminated Push button Switches Types AL, AOL, AJL or AVL may be followed by F or G, followed by D or N, may be followed by E. ALTERNATE: Type AL* or AOL* followed by D or N.
 - (5) Illuminated Selector Switches Types ASLD, ASLN.
 - (6) Pilot lights Types APN, APNE, APD, APDE, APDG, APDGE; N Series (Panel Cutout Dimensions, 30 mm. diam).
 - (1) Push button Switches, Types AB, AO, AT, UB, UO, UT, UW or ABB may be followed by Q, followed by N.
 - (2) Selector Switches Types ASN, ASTN.
 - (3) Selector Push button Switches Type ABN may be followed by 6, 7 or 9, may be followed by L
 - (4) Illuminated Push button Switches Types ALN, ALNE, AOLN, AOLNE, ULQN, UOLQN; Types ALLN, ABLN. ALTERNATE: Types AL*N, AOL*N.
 - (5) Pilot lights Types APN, APNE, APNG, APNGE, UPQN or UPQNE; TWD/TW Series (Panel Cutout Dimensions, 22 mm. diam).
 - (1) Push button Switches Types AB, AO, AJ, AK, AT, AV, AX, AY or AZ may be followed by F, G, H or Q, followed by WD or W. ALTERNATE: Types AB*WD, AB*W, AO*WD, AO*W, AK*W, AK*WD, AX*W, AX*WD.
 - (2) Selector Switches Type AS or ASH followed by WD or W. ALTERNATE: Types AS*WD, AS*W.
 - (3) Selector Push button Switches Types ASBWD, ASBW.
 - (4) Monolever Switches Types ARW, ARWL.
 - (5) Illuminated Push button Switches Types AL, AOL, AJL, AVL, AYL or AZL may be followed by F, H or Q, followed by WD or W. ALTERNATE: Types AL*WD, AL*W, AOL*WD, AOL*W.
 - (6) Illuminated Selector Switches Type ASL or USL may be followed by H, followed by WD or W. ALTERNATE: Types ASL*WD, ASL*W; TWS Series (Panel Cutout Dimensions, 25mm diam).
 - (1) Push button Switches Types AB, AO, AJ, AK, AT, AV, AY, AZ, UB or UO may be followed by F, G, or Q, followed by S. ALTERNATE: Types AB*S, AO*S.
 - (2) Selector Switches Type ASS.
 - (3) Illuminated Push button Switches Types AL, AOL, AJL, AVL, UL or UOL may be followed by F, G or Q, followed by S. ALTERNATE: Types AL*S, AOL*S.
 - (4) Illuminated selector switches Types ASLS, USLS.
 - (5) Pilot lights Types APWD, APHWD, APQWD, ALTERNATE: Type AP*WD; Types APW, APHW, APQW, ALTERNATE: Type AP*W; Types UPQS, UPQMS, ALTERNATE: Type UPQ*S; Types APS, UPQW, APWN.
- Cam switches Types ACSNO, ACSNK, UCSQO, UCSQM followed by additional numbers and letters.
TW Series Alternate Designation: (1)Contact Block.

