HE3B ø16mm Redundant Contact Switch

Key features:

- 3-position functionality (OFF ON OFF) as required for manual robotic control
- Provides a high level of safety based on human behavioral studies that determine personnel may squeeze OR let go when presented with a panic situation
- Contacts will not re-close when released from Off→On (3→1) (per IEC60204-1; 9.2.5.8)
- Multiple contacts for enhanced reliability
- Snap acting contacts from position 1 to 2
- Available with or without rubber cover





Part Numbers

Style			Part Numbers
	Without Rubber Cover		HE3B-M2
		Yellow	HE3B-M2PY
	With Rubber Cover	Black	HE3B-M2PB
		Gray	HE3B-M2PN1

Accessories Replacement Rubber Cover

Appearance	Color	Part Number	Material
	Yellow	HE9Z-D3Y	Silicon
	Black	HE9Z-D3B	Rubber
	Gray	HE9Z-D3N1	NBR/PVC polyblend

Lock Nut Tool

Appearance	Part Number	Material
	MT-001	Metal

Specifications

•		
Conforming to Standards	UL508 (UL recognized), CSA C22.2, No. 14 (c-UL recognized) IEC/EN 60947-5-1, IEC/EN 60947-5-8 (TÜV approval)	
Application Standards	ISO 12100-1, -2, EN 12100-1, 2, IEC 60204-1 / EN 60204-1 ISO 11161 / pren 11161, ISO 10218 / EN 775 ANSI/RIA R15.06, ANSI B11.19	
Operating Temperature	-25 to +60°C (no freezing)	
Operating Humidity	45 to 85% RH maximum (no condensation)	
Storage Temperature	-40 to +80°C (no freezing)	
Pollution Degree	2 (inside panel, terminal side) 3 (outside panel, operator side)	
Contact Resistance	50mΩ maximum	
Insulation Resistance	Between live & dead metal parts: $100 M\Omega \; \text{maximum}$	
	Between positive & negative live parts: $100 M\Omega \; \text{minimum}$	
Impulse Withstand Voltage	1.5kV	
Operating Frequency	1200 operations/hour	
Mechanical Life	Position 1→2→1: 1,000,000 operations minimum	
	Position 1→2→3→1: 100,000 operations minimum	
Storage Temperature Pollution Degree Contact Resistance Insulation Resistance Impulse Withstand Voltage Operating Frequency	-40 to +80°C (no freezing) 2 (inside panel, terminal side) 3 (outside panel, operator side) 50mΩ maximum Between live & dead metal parts: 100MΩ maximum Between positive & negative live parts: 100MΩ minimum 1.5kV 1200 operations/hour Position 1→2→1: 1,000,000 operations minimum	


Specifications con't

•	100,000 operations minimum at rated load	
Operating Extremes	150m/s ² (15 G)	
Damage Limits	500m/s ² (50 G)	
Operating Extremes	5 to 55Hz, applitude 0.5mm minimum	
Damage Limits	16.7Hz, applitude 1.5mm minimum	
	0.110" quick connect / solder terminal	
ed Wire Size	0.5mm² maximum / 1 line (20AWG)	
Resistance	310 ~ 350°C / 3 seconds maximum	
ng Strength	20N minimum	
ed Screw Torque	0.68 to 0.88Nm	
otection	with rubber cover: IP65, without rubber cover: IP40 (IEC 60529)	
hort-Circuit Current	50A (125V)	
ed Short Circuit Protection	125V/10A fast blow fuse (IEC 60127-1)	
ng Force	500N minimum	
	without rubber cover - Approx. 14g with rubber cover - Approx. 18g	
	Damage Limits Operating Extremes	

Contact Ratings

Rated Insulation Voltage (Ui)		125V		
Thermal Current (lth)		3A		
Rated Operating Voltage (Ue)		30V	125V	
AC	Resistive Load (AC-12)	-	1A	
	Inductive Load (AC-15)	-	0.7A	
DC	Resistive Load (DC-12)	1A	0.2A	
	Inductive Load (DC-13)	0.7A	0.1A	
Contact Configuration		2 contacts (DPDT)		
Minimum Applicable Load		AC/DC5V 1mA reference		
	AC DC	AC Resistive Load (AC-12) Inductive Load (AC-15) Resistive Load (DC-12) Inductive Load (DC-13)	th) 3.0 chage (Ue) 30V AC Resistive Load (AC-12) — Inductive Load (AC-15) — Resistive Load (DC-12) 1A Inductive Load (DC-13) 0.7A ction 2 contact	


Circuit Diagrams Terminal Circuit Diagrams (bottom view)





 ³ position switch: 2 contacts, terminal no. = between NO1-C1, between NO2-C2
 Use between NO-C for OFF→ On→ OFF 3 position switch (NC is not used).


Operating Characteristics






Using rubber boot will change the operating force depending on the operating temperature.

Dimensions (mm) Without Rubber Cover




With Rubber Cover



All dimensions in mm

Mounting Hole Layout





- 1. Recommended Lock Nut Torque: 0.68 to 0.88Nm.
- 2. Use a lock nut tool to screw on the lock nut (see page 371).
- 3. To retain the switches waterproof performance, do not penetrate the rubber cover.
- 4. Remove the rubber cover projection if you do not want a positioning hole. (Do not penetrate the rubber cover).